

INFO TOWER™

Custom Printed Interlocking Panel Display

SETUP INSTRUCTIONS

PREVENTION & TREATMENT
★ RESOURCE PRESS ★

1

Lay out all 8 panels, 2 headers and 1 base on the floor.

Place the base on the floor, straighten the left and right side flaps upwards.



2

Insert each panel into the slot of the base by interlocking each other.



3

Choose the panels you prefer to go on the top and bottom.

Continue interlocking all 8 panels until you reach the top.



6



4



Alternative structures can be made using 2, 4 or 6 panels.

5



Complete your Info Tower™ display by interlocking the 2 headers on the top panel.

Final Product